



UNIKON ANC Ring Marker Firmware Update 15th February 2010

This update refers to the ANC Grey Ring Marker mainly used with profi Club bases in Scotland by the SHU. Before you start the UPDATES please familiarise yourself with the steps involved then follow the steps carefully.



1. Make sure that all club equipment system switched off.
2. Make sure ring marker is NOT connected to the profi club base
3. Insert the security token in to the ring marker (as above picture)
4. Connect your PC to the Club base (Using the connector on the side of the profi base)



5. Run the ANC 3.92 update program
6. Select the comport that the device is connected to e.g. If this is a USB adapter provided by UNIKON the name will be Prolific USB to serial comport (Com xx) replace the xx with the comport number of your device.
7. Click Update
8. Press and hold the "0" key on the profi keypad
9. Whilst holding the "0" key switch ON the profi club base
10. When the base says "ESA Prog Mode" release the key

ESA Prog Mode

11. Now immediately Connect the ring marker (within 5 seconds)
12. The ANC Ring Marker will start to update

Programming XXXX

13. When the ANC update program says "update successful" switch off the professional base. If you get a message saying update failed repeat steps above making sure that you have selected the correct com port.