



UNIKON Champ Firmware Update 15th February 2010

This update refers to the Champ system. Before you start the UPDATES please familiarise yourself with the steps involved then follow the steps carefully.

Caution

Before attempting this update, please ensure that the pocket clock or Champ solo are not in Race Mode. You can make sure that there are no active races by using the menu option "Kill race".

1. Make sure the UCS Ring Marker has a time signal and is connected to your computer.
2. Leave the security token in the Ring Marker
3. Connect the Grey moulded cable to the connector on the rear of the UCS labelled UNIKON
4. Make sure the Champ Base station is disconnected from the UCS by same grey cable from the rear of the Champ base.
5. Download the Champ update from www.pigeon-ets.com or insert the UNIKON Manager 2010 CD and select **Champ firmware v3.06** when screen appears.
6. An update screen will appear; Select the comport that UNIKON is using and then click update
7. Now connect your champ base to the club system by connecting the grey moulded cable to the back of Champ (You will need to do this within 10 seconds for the upgrade to commence)
8. If connected in time the upgrade will start and begin
9. Once completed it will display upgrade completed on screen and the new firmware version in the clock.
10. To upgrade all the members clocks just simply place the members pocket clock into the club base
11. For a champ solo please follow steps 1-6



This process only needs to be completed once, to upgrade other member's clocks simply insert there pocket clocks into the Club base.