



UNIKON Professional Firmware Update 16th March 2009

To update the Professional firmware the following procedure must be completed:

Caution

Before attempting this update, please ensure that the pocket clock or champ solo are not in Race Mode. To ensure this make sure the clock has been struck off all recent races and also get the member to clear clock by erasing training.

1. Make sure the Ring Marker has time signal and is connected to the PC
2. Make sure the Professional Base station is powered down (this can be done by removing the grey cable from the back of the base)
3. Insert the UNIKON Manager 2009 CD and select **Professional firmware v3.00** when screen appears
4. An update screen will appear; Select the comport that UNIKON is using and then click update. The default comport for USB users is Prolific USB to serial Adapter
5. Connect your base station up to club system within 10 seconds for the upgrade to commence.
6. If connected in time the upgrade will start and begin to the current firmware release
7. Once completed it will display upgrade completed on screen and the new firmware version in the clock.
8. To upgrade all the members clocks just simply place the members pocket clock into the club base

This process only needs to be completed once, to upgrade other member's clocks.